



ROCKSOLID® LOW GLOSS WET LOOK LACQUER

DESCRIPTION AND USES

RockSolid® Low Gloss Wet Look Lacquer seals and protects concrete and masonry surfaces from the damaging effects of water, chemicals and UV light. This solvent-based formula forms an extremely durable, protective barrier to keep water out, protect against stains and extend the life of the concrete surface. The “wet look” finish beautifies decorative concrete, stone, pavers and masonry surfaces. Application is quick and easy using a solvent-resistant pump sprayer or paint roller.

Low Gloss Wet Look Lacquer is suitable for use on interior and exterior concrete and masonry surfaces including previously stained or sealed concrete, pavers, stone, slate, tile, stucco and more. Do not use on asphalt. Wet Look Lacquer is ideal for driveways, walkways, porches, patios, pool decks and more. If topcoating freshly stained concrete, no surface preparation is necessary. See stain labels for recommended topcoat times. Note: Surfaces previously sealed with RockSolid Low Gloss Wet Look Lacquer may be sealed again with this product.

PRODUCT FEATURES

- Seals and enhances masonry, decorative concrete, pavers, natural stone and more
- Excellent water repellency
- Long-lasting solvent-based formula
- Excellent protection against stains, chemicals, abrasion and grease

PRODUCTS

SKU	DESCRIPTION
293444	1-Gallon Low Gloss Wet Look Lacquer
293534	5-Gallon Low Gloss Wet Look Lacquer

PRODUCT APPLICATION

READ ALL INSTRUCTIONS CAREFULLY BEFORE STARTING PROJECT

SURFACE PREPARATION

Proper surface preparation is critical to achieve best results. Allow newly poured concrete to cure for a minimum of 28 days. Sweep away all loose dirt, debris and remove any vegetation that could interfere with application and performance. If necessary, use a wire brush or sander to remove any loose or unsound concrete or masonry. Remove any efflorescence with RockSolid Efflorescence Remover (sold separately). Clean the entire surface, including any oil or grease spots with RockSolid Heavy Duty Cleaner (sold separately). Scrub with a stiff bristle brush or broom. Rinse thoroughly with fresh water. A power washer is preferred. Repeat as necessary to completely clean and rinse. Allow to dry completely before sealing. Hazing may occur if lacquer is applied to a damp surface.

PRODUCT APPLICATION (cont.)

APPLICATION

RockSolid Low Gloss Wet Look Lacquer is ready to use. Do not thin. Use only when air (ambient) temperature is between 50-90°F (10-32°C) and the relative humidity is below 85% during the day and night. **Do not apply in direct sunlight.** Do not apply if rain is expected within 24 hours. Use in a well ventilated area.

Mask adjacent surfaces to allow spray application up to all edges. Protect delicate foliage from overspray. Apply using a solvent-resistant pump sprayer with an adjustable spray tip. Shake or swirl container to mix product. Fill solvent-resistant pump sprayer with sealer, then fully pressurize the sprayer. Set the spray tip to a medium-fine mist and spray 10-12” from the surface. An alternate method is to apply with a 3/8” or 1/2” nap roller from a paint tray. Do not pour the sealer directly on the surface or allow to puddle.

Apply the sealer evenly, using a circular or oval pattern to saturate the surface. Start and stop the sprayer just off the work area to prevent drips. For larger areas, work in 6’x6’ sections at a time before moving to the next section. Apply a saturating coat so the surface remains wet for several minutes before sealer is absorbed. Wait 5-10 minutes then back roll with a 3/8” to 1/2” nap roller to pick up any puddles and soften overlap marks. A second coat is recommended for more porous surfaces. Wait until the first coat is dry to the touch and follow the same application method and back roll. Occasional touch-up or recoat may be necessary for areas subject to heavy foot or vehicle traffic.

COVERAGE

Each gallon covers 200 square feet (single coat). The actual coverage will vary depending on the porosity of the surface. Dense surfaces will require only one coat. Porous surfaces may require additional coats.


DRY TIME

Dry time is based on 70°F and 50% relative humidity. Allow longer dry time at lower temperatures and higher humidity. Wet Look Lacquer will dry to the touch in 30 minutes. Allow a minimum of 2 hours for foot traffic. Wait 24-48 hours before returning heavy items, furniture and vehicles. The surface will be fully cured in 72 hours.

CLEAN-UP

Wash tools and equipment with mineral spirits or lacquer thinner. Clean spills with mineral spirits or lacquer thinner. Properly dispose of all soiled rags and unused product.

CAUTION: KEEP OUT OF REACH OF CHILDREN – DO NOT TAKE INTERNALLY.

<small>•TRUSTED QUALITY SINCE 1921•</small> RUST-OLEUM®  <small>THE WORLD'S TOUGHEST COATINGS™</small>	TECHNICAL DATA	RSD-15
ROCKSOLID® LOW GLOSS WET LOOK LACQUER		

PHYSICAL PROPERTIES

		LOW GLOSS WET LOOK LACQUER
Resin Type		Acrylic
Pigment		None
Solvent		Acetone, Xylene
Weight	Per Gallon	7.3 lbs.
	Per Liter	0.90 kg
Solids	By Weight	20.9%
	By Volume	15.7%
Volatile Organic Compounds		<650 g/l (5.4 lbs./gal.)
Practical Coverage		200 sq. ft./gal. (single coat) Actual coverage will vary depending on the porosity of the surface
Dry Times @ 70-80° F (21-27°C) and 50% Relative Humidity	Touch	30 minutes
	Recoat	1-2 hours
	Foot Traffic	2 hours
	Full Cure	72 hours
Shelf Life		3 years
Flash Point		-4°F (-20°C)
Safety Information		For additional information, see SDS

The technical data and suggestions for use contained herein are correct to the best of our knowledge, and offered in good faith. The statements of this literature do not constitute a warranty, express, or implied, as to the performance of these products. As conditions and use of our materials are beyond our control, we can guarantee these products only to conform to our standards of quality, and our liability, if any, will be limited to replacement of defective materials. All technical information is subject to change without notice.